

CONTENTS

Sections :-

Page	
1. Installation	2
2. Open Program, Create Cause Effect File	3
• Adding / deleting panels	
• Folder management	
• File naming	
3. Main Editor Window for Configuring Cause and Effect	7
1.View Menu.	7
2.Panal Layout Menu	8
3.Special Functions	9
4. Sensitivity	12
5. Sensitivity - Day Night: Settings	13
6. Select Output	14
7. Allocate Zone/Groups	22
8. Edit texts	23
9. Print	24
10. DOWNLOADING TO PANEL	25
APPENDIX / TIPS	31

Installation

PC requirements :-

PC tower –

Pentium 2 – 4 (500MHz and Above)

128Mb Ram

Floppy Disk Drive , CD-ROM or If downloading from Internet (Modem)

Hard Disk = 2GB At Least

Software :


Operating Systems Win 98 SE, Win2000, Windows ME, Windows NT, Win XP

Software Applications : If C&E was downloaded from Internet .


User will need Win RAR Application to Unzip/unRAR downloaded Cause and Effect file.

Installation Guide setup.


Click on Setup. If file is in Win RAR format. Run Win RAR , Then unzip/un compress file to a folder then click setup



Install and follow instructions. Accept License and choose program folder path.



Once Installed, Run program either via shortcut or from programs Menu.



3. CAUSE/EFFECT PROGRAMMING SYSTEM CABLE CONNECTIONS FOR DOWNLOAD

1.PC to Premier AL / GLOBAL NET REP	Null Modem Cable
2.PC USB PORT to Premier AL or PC USB PORT to Premier AL GLOBAL NETWORK REPEATER	USB to Serial COMM D-TYPE Converter Box / Unit + 1 USB CABLE + 1 NULL MODEM CABLE

This document is a description of the cause/effect programming system for the Premier AL network system. The equipment is currently limited to two panel types, the Premier AL Global network repeater and the Premier AL 1-4 loop analogue addressable panel.

Each job designed on this system will have a 5 digit contract number that is included in all of the file-names used for that job, and is also the name of the directory where the files are stored, whether on a hard disk or a floppy disk. There will also be a twenty character contract name to be specified, together with a twenty character name for each panel on the system.

Once a job has been fully designed, a wide variety of printouts can be generated for reference, and a hex file will be generated for each appropriate panel that can then be downloaded into that panel directly from a computer, or may be programmed into an appropriate EPROM or EEPROM first, and then the EPROM taken to the panel and installed.

First Create A JOB FILE .If no existing File/ Panel Cause And Effect file is present. Select 1. New Job. Fill in Fields , i.e job name , file number and folder path etc

Enter New Premier AL Design Details

Quit


Job Number
Please enter the JOB/CONTRACT number as 5 digits.
33333

Path for Design Files
Please enter the directory path for the design files. Press 'ENTER' to accept path shown.
C:\33333\


Job Name
Please enter the overall JOB/CONTRACT name.
MANUAL DEMO

Start | Speed... | DC+... | Kasp... | software | PCPR... | Zeta A... | al_pro... | Enter ... | 22:19


If an existing File/ Panel Cause And Effect file is present. Then click 2.Edit job. Find the file via folders . Double click on job number



If creating A new Panel. Click Panel Menu, and Add Panel. Choose Panel Type.
 *****Ignore 7.Computer System (This Option is not relevant)*****




Once the Panel Has been created, it now needs editing
Highlight Panel in Existing panel Window and Click Edit Panel Data Menu




EDIT PANEL DATA MENU BRINGS UP A NEW WINDOW. WHICH IS WHERE THE USER CAN CONFIGURE CAUSE AND EFFECT

The Grey Menu Bar , is where the User Defines/Sets Premier AI Function and Behaviour.




1.View Menu. Shows the Panels and the Available flags, i.e Cause types, e.g, Common fire.




2. Panel Layout Menu. User defines, Number of Loops, Repeaters(LOCAL), I/O Boards.etc


Use the arrow keys, to define the number of repeater s, i/o boards , loop cards.




3.11.Special Functions > Time Functions > Panel Delay. User defines Delay Duration and Start / Stop Time.




3.12.Special Functions > Time Functions > DAY/NIGHT . User defines Day and Night mode settings. After office Hours Fyreye Detectors will go to Night time sensitivity settings.



3.13Special Functions > Time Functions > Software Timers. User can set software timer events. Only 1 Group can a software timer be allocated. (not to a zone)



3.21 Special Functions > Time Functions > Access code. Type Old code to enter new code



3.31 Special Functions > Time Functions > Network Responses. User text is recommended. User defines if or how a panel responds to network flags, causes, events etc



3.32 Special Functions > Time Functions > Platform sounders. User declares platform sounder that need configuring .Hence are then controllable by the user , and can be programmed as a Loop output.(Effect) ****USE FOR ZETA SOUNDER BASE FEA SB****

Job Details
 Job Number 11111 Job Name madagascar
 Panel Number 5 Panel Name SWANSEA Directory C:\CauseANDEffect

Current Settings For Loop 1
 Number of Addresses Selected 1

ADR	POINT	TEXT	TYPE	SOUNDER
001			NON-ANALOGUE	---
002			NON-ANALOGUE	PLATFORM SOUNDER
003			NON-ANALOGUE	---
004			NON-ANALOGUE	---
005			NON-ANALOGUE	---
006			NON-ANALOGUE	---
007			NON-ANALOGUE	---
008			NON-ANALOGUE	---
009			NON-ANALOGUE	---
010			NON-ANALOGUE	---
011			NON-ANALOGUE	---
012			NON-ANALOGUE	---
013			NON-ANALOGUE	---

Platform Sounder Usage
 Use Platform Sounder
 No Platform Sounder

Confirm Change
 Are you sure that you want to add a platform sounder to address 3 ?
 Yes Yes To All No Cancel

Frame1
 The 'Loop' menu item allows the required loop to be selected.
 The 'Select' menu item allows all addresses to be selected or de-selected by using the Shift key to select ranges.
 The 'Save' menu item allows data to be saved.
 The 'Done' menu item returns to the main panel.
 Clicking on a parameter button while some addresses are selected will update the appropriate parameter for the selected suspect combinations.

4.11 Sensitivity > Default : Settings > Categories The sensitivity option menu. Choose default to declare type of detector (Cause), that are connected . Sensors to be declared as FYREYE ANALOGUE. *******DO NOT DECALRE ZIOU (ZETA INPUT/OUTPUT UNIT AS A FYREYE I/O UNIT)*******

Job Details
 Job Number 11111 Job Name madagascar
 Panel Number 5 Panel Name SWANSEA Directory C:\CauseANDEffect

Current Settings For Loop 1
 Number of Addresses Selected 1

ADR	POINT	TEXT	TYPE	ALERT	FIRE
001			FYREYE ANALOGUE	45	55
002			FYREYE ANALOGUE	45	55
003			FYREYE ANALOGUE	45	55
004			FYREYE ANALOGUE	45	55
005			FYREYE ANALOGUE	45	55
006			FYREYE ANALOGUE	45	55
007			FYREYE ANALOGUE	45	55
008			FYREYE ANALOGUE	45	55
009			FYREYE ANALOGUE	45	55
010			FYREYE ANALOGUE	45	55
011			NON-ANALOGUE	45	NONE
012			NON-ANALOGUE	45	NONE
013			NON-ANALOGUE	45	NONE

Category Options
 Non-Configurable
 Fyreeye Analogue
 Fyreeye I/O Unit

Instructions
 The 'Loop' menu item allows the required loop to be selected.
 The 'Select' menu item allows all addresses to be selected or de-selected. Individual addresses may be selected or de-selected by directly clicking on them in the list.
 The 'Settings' menu item allows either the 'Category', 'Alert Trip', 'Fire Trip', or i/o unit mode to be edited.
 The 'Save' menu item allows data to be saved either for all loops or just the current loop.
 The 'Done' menu item returns to the main panel editing window.
 Clicking on a parameter button while some addresses in the list are selected will try to update the appropriate parameter for the selected addresses, with suitable prompts for any suspect combinations.

These categories are intended to identify which sensitivity settings are suitable for each address. These values will be stored on disk together with the sensitivity codes. During any attempt to download sensitivity codes to the panel, the configured type codes will be uploaded and compared with these categories. If any configured types belong to a different category to that recorded on the PC a warning prompt will be issued and the codes for that address will not be downloaded.

4.12 Sensitivity > Default : Settings > Alert trips User can set alert trips(pre-alarm condition), via the settings menu.

The screenshot shows the 'GLT Premier AL Panel Default Sensitivity Levels' application. The 'Job Details' section shows Job Number 11111, Job Name madagascar, Panel Number 5, Panel Name SWANSEA, and Directory C:\CauseANDEffect. The 'Current Settings For Loop 1' section shows a table of sensor addresses and their alert/fire levels. The 'Alerts' panel on the right shows a list of alert levels: 35, 40, 45, and 50. A text box explains that these settings represent the analogue value at which an Alert (or Pre-alarm) condition will be recognised from a Fyreye analogue sensor.

ADR POINT TEXT	TYPE	ALERT	FIRE
001	FYREYE ANALOGUE	45	55
002	FYREYE ANALOGUE	45	55
003	FYREYE ANALOGUE	45	55
004	FYREYE ANALOGUE	45	55
005	FYREYE ANALOGUE	45	55
006	FYREYE ANALOGUE	45	55
007	FYREYE ANALOGUE	45	55
008	FYREYE ANALOGUE	45	55
009	FYREYE ANALOGUE	45	55
010	FYREYE ANALOGUE	45	55
011	NON-ANALOGUE	45	NONE
012	NON-ANALOGUE	45	NONE
013	NON-ANALOGUE	45	NONE

Alerts

35

40

45

50

These settings represent the analogue value at which an Alert (or Pre-alarm) condition will be recognised from a Fyreye analogue sensor.

Instructions

The 'Loop' menu item allows the required loop to be selected.
 The 'Select' menu item allows all addresses to be selected or de-selected. Individual addresses may be selected or de-selected by directly clicking on them in the list.
 The 'Settings' menu item allows either the 'Category', 'Alert Trip', 'Fire Trip', or i/o unit mode to be edited.
 The 'Save' menu item allows data to be saved either for all loops or just the current loop.
 The 'Done' menu item returns to the main panel editing window.
 Clicking on a parameter button while some addresses in the list are selected will try to update the appropriate parameter for the selected addresses, with suitable prompts for any suspect combinations.

4.13. Sensitivity > Default : Settings > Fire trips. User can program fire trips settings for each individual sensor(cause)

The screenshot shows the 'GLT Premier AL Panel Default Sensitivity Levels' application. The 'Job Details' section shows Job Number 11111, Job Name madagascar, Panel Number 5, Panel Name SWANSEA, and Directory C:\CauseANDEffect. The 'Current Settings For Loop 1' section shows a table of sensor addresses and their alert/fire levels. The 'Fire Trip Levels' panel on the right shows a list of fire trip levels: 55, 60, 65, and 70. A text box explains that these settings represent the analogue value at which a Fire condition would be recognised from a Fyreye analogue sensor. The normal value is 55.

ADR POINT TEXT	TYPE	ALERT	FIRE
001	FYREYE ANALOGUE	45	55
002	FYREYE ANALOGUE	45	55
003	FYREYE ANALOGUE	45	55
004	FYREYE ANALOGUE	45	55
005	FYREYE ANALOGUE	45	55
006	FYREYE ANALOGUE	45	55
007	FYREYE ANALOGUE	45	55
008	FYREYE ANALOGUE	45	55
009	FYREYE ANALOGUE	45	55
010	FYREYE ANALOGUE	45	55
011	NON-ANALOGUE	45	NONE
012	NON-ANALOGUE	45	NONE
013	NON-ANALOGUE	45	NONE

Fire Trip Levels

55

60

65

70

These settings represent the analogue value at which a Fire condition would be recognised from a Fyreye analogue sensor. The normal value is 55.

Instructions

The 'Loop' menu item allows the required loop to be selected.
 The 'Select' menu item allows all addresses to be selected or de-selected. Individual addresses may be selected or de-selected by directly clicking on them in the list.
 The 'Settings' menu item allows either the 'Category', 'Alert Trip', 'Fire Trip', or i/o unit mode to be edited.
 The 'Save' menu item allows data to be saved either for all loops or just the current loop.
 The 'Done' menu item returns to the main panel editing window.
 Clicking on a parameter button while some addresses in the list are selected will try to update the appropriate parameter for the selected addresses, with suitable prompts for any suspect combinations.

5.11 Sensitivity > Day Night: Settings > Categories User can set fire trip values , to each individual sensor , for DAY TIME or NIGHT TIME settings.

GLT Premier AL Panel Day/Night Sensitivity Levels

Loop Select Settings Save Details Done

Job Details
 0 DayTime FYREYE Fire Trips
 NightTime FYREYE Fire Trips

Job Name madagascar
 Panel Number 5 Panel Name SWANSEA Directory C:\CauseANDEffect

Current Settings For Loop 1
 Number of Addresses Selected 0

ADR	POINT	TEXT	TYPE	DAY	NIGHT
001			NON-ANALOGUE	NONE	NONE
002			NON-ANALOGUE	NONE	NONE
003			NON-ANALOGUE	NONE	NONE
004			NON-ANALOGUE	NONE	NONE
005			NON-ANALOGUE	NONE	NONE
006			NON-ANALOGUE	NONE	NONE
007			NON-ANALOGUE	NONE	NONE
008			NON-ANALOGUE	NONE	NONE
009			NON-ANALOGUE	NONE	NONE
010			NON-ANALOGUE	NONE	NONE
011			NON-ANALOGUE	NONE	NONE
012			NON-ANALOGUE	NONE	NONE
013			NON-ANALOGUE	NONE	NONE

DayTime Fire Trips

55
60
65
70

These settings represent the analogue value at which a Fire condition would be recognised from a FYREYE analogue sensor. The normal value is 55. These are the values used in the daytime when day/night mode is active.

Instructions

The 'Loop' menu item allows the required loop to be selected.
 The 'Select' menu item allows all addresses to be selected or de-selected. Individual addresses may be selected or de-selected by directly Control-clicking on them in the list, or using the Shift key to select ranges.
 The 'Settings' menu item allows either the Daytime or Nighttime Fire Trip to be edited.
 The 'Save' menu item allows data to be saved either for all loops or just the current loop.
 The 'Done' menu item returns to the main panel editing window.
 Clicking on a parameter button while some addresses in the list are selected will try to update the appropriate parameter for the selected addresses, with suitable prompts for any suspect combinations.

6.11 Select Output > Loop outputs. The user **MUST DECLARE** outputs(effect). If a **Sounder** is not declared , then it will not operate, even if the loop has configured it , on the **Premier AL Loop Output C&E** in the the engineers menu. All loop output devices must be set, with **Channel A(bit 0), B(bit 1), C (bit 2) Command settings.**

GLT Premier AL Cause/Effect - Premier AL Panel Main Editor

View Panel Layout Special Functions Sensitivity Select Output Allocate Zones/Groups Edit Texts Print Quit

Job Details
 0 Job Number 11111 Job Name madagascar
 Panel Number 5 Panel Name SWANSEA Directory C:\CauseANDEffect

Specify New Loop Output

LOOP	POINT						CHANNEL
1	001	007	013	019	025	031	A
	002	008	014	020	026	032	B
	003	009	015	021	027	033	C
	004	010	016	022	028	034	
	005	011	017	023	029	035	
	006	012	018	024	030	036	


Click on the required loop number, point address and channel to specify a new loop output. Click on 'OK' when the appropriate values are highlighted to continue to enter a user text for the new output, or click on 'Exit' to abandon specifying a new loop output.

Loop Output: Text

Enter user text for loop output L1:009A

SOUNDER

Once a loop out put is declared. Then the User can manipulate/program its behaviour(effect). Highlight the loop output and **CLICK** the **CAUSES** Button.



Choose either Local for a Single Panel. Or Network for a network of Panels.

*****WARNING.MAKE SURE YOU ARE FULLY CAPABLE AND UNDERSTAND CAUSE AND EFFECT. RECORD STATE OF CAUSES > AND RECORD NEW CAUSES CREATED, SO THAT IT CAN BE DELETED IF PANEL DOES NOT OPERATE OR GIVES A FAULT) USER MUST RETRACE STEPS, IN CASE USER HAS TO DELETE A BADLY CREATED CAUSE AND EFFECT*****

CHOOSING LOCAL WILL BRING UP ARANGE OF FLAG?CAUSE TYPES WHICH ARE DEFINED :-

- **Zone Fire Single Knock Operate Until Reset**
- One single device in fire within the assigned zone will cause the selected output to operate until SYSTEM RESET.
- **Zone Fire Single Knock Operate Until Silence**
- As above except operates until SILENCE ALARMS is pressed.
- **Zone Fire Double Knock Operate Until Reset**
- Two devices in fire within the assigned zone will cause the selected output to operate until SYSTEM RESET.
- **Zone Fire Double Knock Operate Until Silence**
- As above except operates until SILENCE ALARMS is pressed.
- **Zone Fire Triple Knock Operate Until Reset**

- Three devices in fire within the assigned zone will cause the selected output to operate until SYSTEM RESET.
- **Zone Fire Triple Knock Operate Until Silence**
- As above except operates until SILENCE ALARMS is pressed.
- **Zone Alert Operate Until Causes Clear**
- Any single device in alert within the assigned zone will cause the selected output to operate until no longer in alert.
- **Zone Fault Operate Until Causes Clear**
- Any single device in fault within the assigned zone will cause the selected output to operate until no longer in fault.
- **Zone Indication Operate Until Causes Clear**
- Any single indication only device (not fire, alert or fault mode) operated within the assigned zone will cause the selected output to operate until the signal is removed.
- **Common Fire Operate Until Reset**
- Any device in fire will cause the selected output to operate until SYSTEM RESET.
- **Common Fire Operate Until Silence**
- As above except until SILENCE ALARMS is pressed.
- **Common Alert Operate Until Causes Clear**
- Any device in alert will cause the selected output to operate until no longer in alert.
- **Common Fault Operate Until Causes Clear**
- Any device in fault will cause the selected output to operate until no longer in fault.
- **Common Indication Operate Until Causes Clear**
- Any indication only device (not fire, alert or fault mode) operated will cause the selected output to operate until the signal is removed.
- **Alarms Silenced Operate Until Causes Clear**
- Pressing the Alarms Silenced (or remote Alarms Silenced) control will cause the selected output to operate until the signal is removed.
- **System Reset Operate Until Causes Clear**
- Pressing the System Reset (or remote System Reset) control will cause the selected output to operate for 10-15 seconds until the signal is removed.
- **Evacuate Operate Until Causes Clear**
- Pressing the Evacuate (or remote Evacuate) control will cause the selected output to operate until the system is no longer in Evacuate.
- **Zone Fire Single Knock Inhibit Until Reset**


- Any single device in fire within the assigned zone will prevent operation of the selected output until SYSTEM RESET. If the selected output is already operating, this cause condition will revert to its quiescent state.
- **Zone Fire Double Knock Inhibit Until Reset**
- Any two devices in fire within the assigned zone will prevent operation of the selected output until SYSTEM RESET. If the selected output is already operating, it will revert to its quiescent state.
- **Zone Alert Inhibit Until Causes Clear**
- Any single device in alert within the assigned zone will prevent operation of the selected output until no longer in alert. If the selected output is already operating, it will revert to its quiescent state.
- **Zone Fault Inhibit Until Causes Clear**
- Any single device in fault within the assigned zone will prevent operation of the selected output until no longer in fault. If the selected output is already operating it will revert to its quiescent state.
- **Zone Indication Inhibit Until Causes Clear**
- Any single indication only device (not fire, alert or fault mode) operated within the assigned zone will prevent operation of the selected output until the signal is removed. If the selected output is already operating, it will revert the selected output to its quiescent state.
- **Common Fire Inhibit Until Reset**
- Any device in fire will prevent operation of the selected output until SYSTEM RESET. If the selected output is already operating, it will revert the selected output to its quiescent state.
- **Common Alert Inhibit Until Causes Clear**
- Any device in alert will prevent operation of the selected output until no longer in alert. If the selected output is already operating, it will revert the selected output to its quiescent state.
- **Common Fault Inhibit Until Causes Clear**
- Any device in fault will prevent operation of the selected output until no longer in fault. If the selected output is already operating, it will revert the selected output to its quiescent state.
- **Common Indication Inhibit Until Causes Clear**
- Any indication only device (not fire, alert or fault mode) will prevent operation of the selected output until the signal is removed. If the selected output is already operating, it will revert the selected output to its quiescent state.
- **Alarms Silenced Inhibit Until Causes Clear**
- Pressing the Alarms Silenced (or remote Alarms Silenced) control will prevent operation of the selected output until the signal is removed. If the selected output is already operating, it will revert the selected output to its quiescent state.
- **System Reset Inhibit Until Causes Clear**

- Pressing the System Reset (or remote System Reset) control will prevent operation of the selected output for 10-15 seconds until the signal is removed. If the selected output is already operating, it will revert the selected output to its quiescent state.
- **Evacuate Inhibit Until Causes Clear**
- Pressing the Evacuate (or remote Evacuate) control will prevent operation of the selected output until the system is no longer in Evacuate. If the selected output is already operating, it will revert the selected output to its quiescent state.

CHOOSING NETWORK, WILL BRING A LIST OF PANELS AND CAUSES (FLAGS)
The flag or Cause definitions are the same, as above, with additional Flag/ Causes available. These are:-

3.4.1. Add New Flag.Creating Unique Causes: WARNING.MAKE SURE YOU ARE FULLY CAPABLE AND UNDERSTAND CAUSE AND EFFECT. RECORD STATE OF CAUSES > AND RECORD NEW CAUSES CREATED, SO THAT IT CAN BE DELETED IF PANEL DOES NOT OPERATE OR GIVES A FAULT or A BADLY WRITTEN CAUSE AND EFFECT/MISTAKE)
****** TIP: BACK UP FOLDER THEN CREATE CAUSE AND EFFECT******

When this option is selected, a box appears identifying the new flag number, and offering various option buttons plus a 'Cancel' button. Flag specification takes place in four stages, with appropriate options being given at each stage.



3.4.1.1. Stage 1 - Cause number & Combination Options.

There are six options on offer here, as well as a 'Cancel' button to return to the menu bar options.

3.4.1.1.1. Single Knock

Select this button to specify an individual cause to operate the flag by

itself. This allows for four types of cause:- Common Cause, Loop Cause, Input Cause, or Zone Cause.

3.4.1.1.2. Double Knock

Select this button to specify two individual causes to operate the flag when both causes are active simultaneously. This allows for three types of cause:- Loop Cause, Input Cause, or Zone Cause.

3.4.1.1.3. Triple Knock

Select this button to specify three individual causes to operate the flag when all three causes are active simultaneously. This allows for three types of cause:- Loop Cause, Input Cause, or Zone Cause.

3.4.1.1.4. Single Knock Range

Select this button to specify a range of causes any one of which will operate the flag by itself. This allows for three types of cause:- Loop Cause, Input Cause, or Zone Cause.

3.4.1.1.5. Double Knock Range

Select this button to specify a range of causes to operate the flag when when any two causes are active simultaneously. This allows for three types of cause:- Loop Cause, Input Cause, or Zone Cause.

3.4.1.1.6. Triple Knock Range

Select this button to specify a range causes to operate the flag when any three causes are active simultaneously. This allows for three types of cause:- Loop Cause, Input Cause, or Zone Cause.

3.4.1.2. Stage 2 - Cause Type.

There are four possible options here:-

3.4.1.2.1. Common Cause

This option is only available as a Single Knock cause, and brings up a list of available Common Causes together with an 'OK' button and a 'Cancel' button.

3.4.1.2.2. Loop Cause

This option brings up a box with a list of available loop numbers, a list of possible sensors, and a list of possible sensor status conditions, together with an 'OK' button and a 'Cancel' button.

3.4.1.2.3. Input Cause

This option brings up a box with a list of available inputs together with an 'OK' button and a 'Cancel' button.

3.4.1.2.4. Zone Cause

This option brings up a box with a list of possible zone numbers and a list of possible zone status conditions, together with an 'OK' button and a 'Cancel' button.

3.4.1.3. Stage 3 - Cause Selection.

There are seven variations here:-

3.4.1.3.1. Single Common Cause

This involves clicking on a Common Cause in the list to select it, then clicking on the 'OK' button to proceed to stage 4.

n.b. the Common Cause list will be removed from the screen as soon as the cause is selected, or the 'Cancel' button is operated.

3.4.1.3.2. Single Loop Cause

This involves clicking on a loop number, and a sensor number, and a sensor status condition before operating the 'OK' button. An appropriate number of loop causes need to be selected depending upon whether Single-Knock, Double-Knock or Triple-Knock has been specified before proceeding

to stage 4.

n.b. the loop cause list will remain visible until sufficient causes have been selected, or the 'Cancel' button is operated.

3.4.1.3.3. Single Input Cause

This involves clicking on an input number then operating the 'OK' button. An appropriate number of input causes need to be selected depending upon whether Single-Knock, Double-Knock or Triple-Knock has been specified before proceeding to stage 4.

n.b. the input cause list will remain visible until sufficient causes have been selected, or the 'Cancel' button is operated.

3.4.1.3.4. Single Zone Cause

This involves clicking on a zone number and a zone status condition before operating the 'OK' button. An appropriate number of zone causes need to be selected depending upon whether Single-Knock, Double-Knock or Triple-Knock has been specified before proceeding to stage 4.

n.b. the zone cause list will remain visible until sufficient causes have been selected, or the 'Cancel' button is operated.

3.4.1.3.5. Range of Loop Causes

This involves clicking on a loop number, and a range of sensor numbers, and a sensor status condition before operating the 'OK' button. The range of sensor numbers is selected by moving the mouse pointer to the first sensor number, pressing the left mouse button and dragging the mouse pointer to the last sensor number before releasing the button. The selected devices will be highlighted.

n.b. the loop cause list will be removed from the screen when either a valid cause is selected, or the 'Cancel' button is operated.

3.4.1.3.6. Range of Input Causes

This involves selecting a range of input numbers before operating the 'OK' button. The range of input numbers is selected by moving the mouse pointer to the first input number, pressing the left mouse button and dragging the mouse pointer to the last input number before releasing the button. The selected inputs will be highlighted.

n.b. the input cause list will be removed from the screen when either a valid cause is selected, or the 'Cancel' button is operated.

3.4.1.3.7. Range of Zone Causes

This involves selecting a range of zone numbers, and a zone status condition before operating the 'OK' button. The range of zone numbers is selected by moving the mouse pointer to the first zone number, pressing the left mouse button and dragging the mouse pointer to the last zone number before releasing the button. The selected zones will be highlighted.

n.b. the zone cause list will be removed from the screen when either a valid cause is selected, or the 'Cancel' button is operated.

3.4.1.4. Stage 4 - Clearing Mode Selection.

The options presented here will depend upon the cause type selected, but as soon as one of these options has been selected then the appropriate cause will be added to the definition for the current flag, and the program will return to stage 1 above, still for the same flag, so that further causes may be specified for that flag.

3.4.1.4.1. On Till Cause Clear

This option is available for all cause types, and means that the flag will only be activated while the cause itself is active.

3.4.1.4.2. On Till Silence

This option is available for 'Fire' causes only, and means that the flag will only be activated until the alarms are silenced.

3.4.1.4.3. On Till Reset

This option is available for 'Fire' causes only, and means that the flag will remain active until the system is reset. This normally has the same effect as 'On Till Cause Clear' because a 'Fire' cause is usually latching until reset.

3.4.1.4.4. Off Till Cause Clear :This option is available for all cause types, and means that the flag will be forced off (inhibited) while the cause is active.


WHEN THE CAUSE IS CREATAED , THE USER MUST SAVE CAUSE, AT THIS POINT OR CAUSE WILL NOT BE PROGRAMMED. THIS CAUSE IS PLACED INTO THE HEX FILE FOR DONLOADING TO PANEL. THE HEX FILE RECORDS THE PANEL CAUSE AND EFFECTS.

LOOP OUPUTS CAN BE DELETED , BUT THE CAUSES IN THEM , MUST BE DELETED FIRST.

6.12 Select Output > Panel outputs. Software Timers and I/O board Programming.

Cause and Effect are the Same as described for Loop Outputs.

WARNING.MAKE SURE YOU ARE FULLY CAPABLE AND UNDERSTAND CAUSE AND EFFECT. RECORD STATE OF CAUSES > AND RECORD NEW CAUSES CREATED, SO THAT IT CAN BE DELETED IF PANEL DOES NOT OPERATE OR GIVES A FAULT)



7.11 Allocate Zone/Groups > Allocate > Allocate Zone/Groups to Points.

This Section is where the USER , plans a list of which zones and groups the sensor/detectors are to be allocated or placed in. Also Grouping in common or local . There are 32 Zones, which are mutually exclusive. If sensor 1 is in zone 1, it cannot be placed in any other Zone upto zone 32. It can however be placed in any zone/group from 33 to 248.

GLT Premier AL Panel Zone/Group Allocation

View Allocate Done

Job Details

0 Job Number 11111 Job Name madagascar

Panel Number 5 Panel Name SWANSEA Directory C:\CauseANDEffect

Select up to 1 zone (1-32) and/or up to 7 groups (33-255), 1 loop and any combination of points, then Click on 'ADD' to add the selected zone/groups to the selected points, or click on 'REMOVE' to remove the selected zone/groups from the selected points. Use the Shift key to select ranges, or the Control key for multiple individual addresses. Click on 'Done' when finished.

Point Selection

Loops

1

Points

1	10	19	28	37	46	55	64
2	11	20	29	38	47	56	65
3	12	21	30	39	48	57	66
4	13	22	31	40	49	58	67
5	14	23	32	41	50	59	68
6	15	24	33	42	51	60	69
7	16	25	34	43	52	61	70
8	17	26	35	44	53	62	71
9	18	27	36	45	54	63	72

Zones/Groups

001 ()

002 ()

003 ()

004 ()

005 ()

006 ()

007 ()

008 ()

009 ()

010 ()

011 ()

012 ()

ADD REMOVE Done

Premier AL Zone/Group Allocation

n.b. Although the word ZONE is generally used in this area, zones 33-255 are reserved for cause/effect operations and are often referred to as groups (including the panel menu pages). Each loop device may be allocated to 1 zone (1-32) and up to 7 groups (33-255). Each panel input may be allocated to up to 8 groups (33-255).

Here is Also where to REMOVE sensors from zones and Groups.

7.12 Allocate Zone/Groups > View >

This screen offers the following menu options:-

Allocate Zone/Groups > View > Zones groups for points

This brings up two boxes, one giving a list of available loops and a list of sensor addresses, while the other gives up to the zone number and up to seven group numbers and a 'Cancel' button. Whenever a loop number and a sensor number are selected, the list of zones/groups identifies the currently allocated zones/groups for that sensor.


Operating the 'Cancel' button clears these boxes from the screen and reenables the menu options.

Allocate Zone/Groups > View > Zones groups for Input


This brings up two boxes, one giving a list of available panel inputs, while the other gives up to eight group numbers and a 'Cancel' button.

Allocate Zone/Groups > View > Point/inputs for zone group.

User can view what is allocated. (L1:001 = Loop 1 , device address 001 is in zone 1)



8.11 Edit texts > Select Text Category >





Here the user can define Point texts, panel name etc.

****remember to press ENTER and also SAVE TEXT LABELS****

REMEMBER TO PRESS ENTER TO SAVE TEXT ON THE LINE. ALSO TO SAVE AFTER EDITING TEXT LABELS. THE DEVICES / SENSORS / POINTS ARE NOW LABELLED AND WILL SHOW UP ON THE DISPLAY OF THE PANEL, and AMS ALARM MANAGER SOFTWARE.

9.11 Print . User Has certain parameters and Cause Effect settings that can be printed. MAKE SURE A PRINTER IS ATTACHED TO PC.






*****THE FACP PANEL EVENT HISTORY LOG IS NOT A PRINTABLE FEATURE. IT IS NOT SUPPORTED.THIS IS BECAUSE IT CANNOT BE UPLOADED.*****

10. DOWNLOADING TO PANEL:

WHEN YOU ARE READY TO COMMIT CAUSE AND EFFECT CONFIGURATION AND SETTINGS TO PANEL. THEN YOU MUST DOWNLOAD CAUSE AND EFFECT FILES TO PANEL VIA SERIAL COMM CONNECTOR CABLE OR USB TO SERIAL COMM CONNECTOR CONVERTER CABLE.

GO INTO THE EDITOR WINDOW BELOW. HIGHLIGHT PANEL FILE. CHECK CHANGES AND CHOOSE PANEL NUMBER WITH PANEL HIGHLIGHTED

****WARNING: DO NOT CHOOSE ANOTHER PANEL NUMBER IF IT DOES NOT MATCH THE HIGHLIGHTED PANEL. DO NOT CHECK CHANGES WITH PANEL 4, WITH PANEL 5 SETTINGS.****



ONCE FINISHED CHOOSE MAKE HEX FILE.

Hex Files

This menu option includes sub-options for either creating hex files for any panels whose cause/effect has changed, creating a hex file for the selected panel, or downloading appropriate data to the selected panel.

If 'Check Changes' is selected then a list of panels whose cause/effect data has been changed since their hex file was last created will be displayed, with the options to re-create hex files for all of the listed panels, or to select individual panels to re-create hex files for. In either case the appropriate hex-file program for each panel will be executed in turn.

If 'Download' is selected then the appropriate download program for the selected panel type will be executed.

If 'Make Hex File' is selected then the appropriate hex-file program for the selected panel will be executed.


n.b. The 'Download' programs that are currently available will be accessible directly from Windows as separate Program Manager items, with a built-in facility to locate and identify the appropriate design files.

NOW GOTO THE COMM PORT AND SET THE RIGHT COMM PORT THAT THE PC DATA CABLE TO PANEL IS CONNECTED TO. (COMM 1 Or COMM 2)


THEN CHOOSE DOWNLOAD TO PANEL. MAKE SURE PC CABLE TO PANEL IS ATTACHED.

**USER WILL BE PROMPTED TO ENTER ACCESS CODE.
(default 8812)**


Once the panel details have been identified, the program requests the current panel access code to be entered. The program then asks whether or not the panel name or job name is to be used for the company logo on the panel, before checking what information is available for downloading.



The program then tries to identify the panel connected to the serial port of the computer. A red Progress Bar indicates communication.



The User will be prompted to ENABLE the SSD DIP SWITCH(WRITE ENABLE/DISABLE), in the PREMIER AL.



*******WARNING, DO NOT DISRUPT OR INTERRUPT DOWNLOAD PROCEDURE OR WHEN PREMEIR AL DISPLAYS “ COMPUTER ACCESS IN PROGRESS PANEL DISABLED”. *******

If Interrupted, repeat whole procedure again as data corruption can occur.

The program will default to using the 'COM1:' port unless another port is specified in the GLTCOMM.INI file. This file may be updated via the menu item in the main menu screen.

Failure to access the panel will terminate the program. If the panel can be accessed, then its identification details will be extracted and checked as described in 3.5.2. below.

3.5.1. Job & Panel Selection

This facility involves the standard Windows style drive and directory selection boxes, plus a list of possible jobs, and a list of possible panels. Each time a new directory is selected the program will check for any design files in that directory, and if it finds any will display a list of the jobs contained in that directory. It will then automatically select the first job (which will normally be the only job in a given directory), and display a list of the panels for that job. If there happens to be more than one job in the same directory, then clicking on the job list will change the selected job and bring up a list of panels for the new job.

Selecting a panel, then Clicking on the 'Download' menu function will continue to the next stage for the selected panel. Clicking on 'Quit' will terminate the program.

3.5.2. Checking Panel Identification.

The identification details retrieved from the panel include the panel's type code, its currently defined number and name, and the version of motherboard software installed.

If the type code returned is not 11 which represents the Premier AL panel, then the program will terminate.


If the panel number returned is different from that specified on the computer, then a prompt will appear asking whether it is required to change the panel's number or not. If 'No' is selected, and the number returned by the panel is not 0 then the program will terminate, otherwise if the number from the panel is 0 then the panel name will be checked, but if 'Yes' is selected then the panel number specified on the computer will be transferred to the panel, and the program will then proceed to check the panel name. Similarly if the panel name returned is different from that specified on the computer, then an option will be given to update the name stored in the panel to that specified on the computer. This time however selecting 'No' will not terminate the program, but proceed directly to the next stage.

n.b. a stand-alone panel will always return a panel number of 0, and this cannot be changed.

3.5.3. Selecting Download Information.

When the panel's identification has been successfully checked, a list of suitable data files existing on the computer will be displayed, with the option to download all of the data, or just selected files. Clicking on 'All' will download all of the available information to the panel, while Clicking on 'Selected' will only download any files that are highlighted in the list.

n.b. A progress bar will be displayed during each download process for reference. Also if the panel has a switch for write-protecting its EEPROM memory, and that switch is in the 'Protected' position, then a warning prompt will be displayed giving the user an opportunity to move the switch into the 'Enabled' position before proceeding with the download, or to terminate the download process.




3.5.4. Uploading Information.

When the panel's identification has been successfully checked, a list of suitable data files existing on the computer will be displayed, with the option to download all of the data, or just selected files. The menu bar will also include an Upload option allowing the following items to be uploaded:-

1. Access Code. If linking to a new panel , and user wants to change access code.
2. Panel Layout. User can check panels layout, and analyse/diagnose any /settings.
3. Delay Parameters. User c check panels delay settings
4. Point Texts (Individual loops or all loops). User can analyse/modify device labels.
5. Input Texts. I/O board names/labels.
6. Point Sensitivity (Individual loops, all loops, or manual). User can analyse/diagnose the sensor / point levels for alert and alarm. i.e 45 alert and 70 alarm
7. Analogue Values (Individual loops or all loops).**SEE DIAGRAM BELOW**
8. Zone/Group Allocation. User can uploads current zone group configuration.
9. Local Cause/Effect. User can analyse/diagnose, cause and effect settlings
10. Network Cause/Effect.
11. Network Responses.


**** Once all or Any of the above information IN Uploaded, it can then be printed via the print menu*******



**Appendix A - Cable Connections for Download
Panel (DB9F) Computer (DB9F) Computer (DB25F)**

2 ----- 3 ----- 2
3 ----- 2 ----- 3
5 ----- 5 ----- 7

This is equivalent to a standard 'NULL-MODEM' type cable that is readily available from many computer stores.



CABLE SHOULD BE 3 CORE AND SCREENED. CABLE LENGTH SHOULD BE AT LEAST A COUPLE OF METRES, OR USER / CUSTOMER CHOICE

TIPS:

BACKUP FOLDERS . ALWAYS BACK UP CAUSE AND EFFECT FOLDERS. SO THAT ANY ERRORS OR FILE CORRUPTION CAN SIMPLY BE RECTIFIED < BY EDITING OR REPLACING WITH A RECENT BACK UP. BACK UP PROCEDURE IS BY SIMPLY COPY/PASTE FOLDER IN WINDOWS. THIS IS ALSO RECOMMENDED FOR WHEN CREATING CAUSE AND EFFECT CHANGES. FIRST BACK UP FOLDER AND THEN CREATE CAUSE AND EFFECT CHANGE.

IF A FAULT OR ZONAL LIGHT DOES NOT DISSAPPEAR FROM THE FRONT PANEL, AND USER HAS DELETED A BADLY WRITTEN CAUSE AND EFFECT. THEN DOWNLOAD A NEW CLEAN/NON PROGRAMMED FILE AND THEN DOWNLOAD THE ORINGINAL CAUSE AND EFFECT FILE.

If Encountering, runtime errors, or programs accesss problems. Press CTRL+ALT+DELETE , and make sure to shut down GLT processes in Background, Then Quit all GLT Cause Effect software, and re open programs again.